

Automotive Racing Products
1863 Eastman Avenue
Ventura, Ca 93003



PROFESSIONAL
QUALITY
FASTENERS

Tel: (805) 339-2200
Fax: (805) 650-0742
www.arp-bolts.com

INSTALLATION METHOD FOR PRO SERIES ROCKER ARM STUD KITS

Part Number: 290-7201 **Application:** 7/16- 1/2 Dia. BB Pontiac

- [1] Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- [2] Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
- [3] Using a thread cleaning tap, clean out all the threads in the cylinder head prior to installation. If your cylinder heads are not set up for screw in rocker arm studs have a professional machine shop machine your heads for screw in studs.
- [4] Using **ARP Ultra-Torque Fastener Assembly Lubricant**, lubricate the coarse end of the rocker arm stud that screws into the cylinder head. **Note:** If the studs protrude into the intake port or water jacket lubricate the studs with **ARP Thread Sealer**.
- [5] Install the push rod guide plates (if applicable).
- [6] Screw the rocker arm studs into the cylinder head and tighten them hand tight. Make sure the bottom side of the hex is seated down against the cylinder head or guide plate (where applicable).
- [7] Tighten the rocker arm studs to the following specifications:

PRELOAD (TORQUE) RECOMMENDATIONS

Aluminum Cylinder Heads 50 ft-lbs.

Cast Iron Cylinder Heads 60 ft-lbs.

If you have any questions or need additional information please contact us at **(805) 339-2200** or by **FAX at (805) 650-0742**